ARCA-SWISS Pico Lens list

* requires 010905, Lens board Pico, 10 mm recessed

Rodenstock HR	Fuji GFX	Sony E	L-Mount	Canon R	Nikon Z	HBD - X	Leica M	Fuji X	HBD - V	Phase One IQ
23 HR Digaron-S	X	X	X	X	X	X	X	X	OK	OK
28 HR Digaron-S	X	X	X	X	X	NO MOVEMENT	X	X	OK	OK
32 HR Digaron-W	X	X	X	X	NO MOVEMENT	NO MOVEMENT	X	X	OK	OK
35 HR Digaron-S	NO MOVEMENT*	NO MOVEMENT*	NO MOVEMENT*	NO MOVEMENT*	NO MOVEMENT*	NO MOVEMENT*	NO MOVEMENT*	NO MOVEMENT*	OK	OK
40 HR Digaron-W	NO MOVEMENT	X	X	X	NO MOVEMENT	NO MOVEMENT	X	X	OK	OK
50 HR Digaron-W	NO MOVEMENT	NO MOVEMENT	NO MOVEMENT	NO MOVEMENT	OK	OK	NO MOVEMENT	NO MOVEMENT	OK	OK
60 HR Digaron-S	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
70 HR Digaron-W	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
90 HR Digaron-SW	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
100 HR Digaron-S	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
105 HR Digaron Macro float	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
138 HR Digaron SW float	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
other Rodenstock										
35 Apo-Sironar digital	X	X	X	X	X	X	X	X	OK*	OK*
45 Apo-Sironar digital	X	X	X	X	X	X	X	X	OK	OK
55 Apo-Sironar digital	OK	OK	OK	OK	OK	OK	NO MOVEMENT	NO MOVEMENT	OK	OK
105 Apo-Sironar digital	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
120 Apo-Sironar digital	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
135 Apo-Sironar digital	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
Schneider										
24 XL Apo-Digitar	X	X	X	X	X	X	X	X	X	X
28 XL Super-Digitar	X	X	X	X	X	X	X	X	OK*	OK*
35 XL Apo-Digitar	X	X	X	X	X	X	X	X	OK*	OK*
43 XL Apo-Digitar	NO MOVEMENT*	NO MOVEMENT*	NO MOVEMENT*	NO MOVEMENT*	NO MOVEMENT*	NO MOVEMENT*	X	X	OK	OK
47 XL Digitar	NO MOVEMENT*	NO MOVEMENT*	NO MOVEMENT*	NO MOVEMENT*	NO TILT*	OK*	NO MOVEMENT*	NO MOVEMENT*	OK	OK
60 XL Apo-Digitar	OK	OK	OK	OK	OK	OK	NO MOVEMENT	OK	OK	OK
60 N Apo-Digitar	OK*	OK*	OK*	OK*	OK*	OK*	OK	OK	OK	OK
80 N Apo-Digitar	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
90 N Apo-Digitar	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
100 N Apo-Digitar	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
100 asph. Apo-Digitar	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
120 N Apo-Digitar	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK
120 asph. Apo-Digitar	OK	OK	OK	OK	OK	OK	OK	OK	OK	OK